



- A) Place a straight edge along the Transom. Mark the Center of the straight edge and line it up with the Center Line of the Transom**
- B) Rest the straight edge on the transom at the center and with a second pair of hands measure B. Rotate straight edge until both measurements are the same.**
- C) This measurement is whatever you choose. If you only have an 8' 2x4 then use that even if the Beam is more than that. The longer the straight edge, the more accurate the arc will be.**